

Spannschrauben wechseln an Fräser: ID 179728

Das Fräswerkzeug ID179728 ist im Auslieferungszustand montiert.
Sonderschlüssel ID134984 **nicht** im Lieferumfang enthalten.


Der Ring (!!Linksgewinde!!) ID179873 ist mittels Schraubensicherungskleber Loctite® 240 (Loctite® „Blau“) eingeklebt.

Durch Erwärmen des Bereichs, in dem sich der Gewinding befindet, den Schraubensicherungskleber auf mind. 150°C erwärmen (evt. mittels Heißluftfön), dann mit dem Spezialschlüssel **ID134984** welcher mit einem Gabelschlüssel SW13 betätigt werden kann, herausdrehen.

!! Beachten Sie dass der Ring ID 179873 ein Linksgewinde hat !!

Der Tausch der Anzugsschraube ID179731 ist erfolgt

Zum Wiedereinkleben des Ringes beachten Sie bitte die entsprechende Gebrauchsanweisung von Loctite®



Changing clamping screws on cutters: ID 179728

The ID179728 milling tool is assembled when delivered.
Special key ID134984 **not** included in delivery.

The ring (!!left-hand thread!!) ID179873 is glued in place using Loctite® 240 threadlocker (Loctite® "blue").


Heat the area where the threaded ring is located and heat the screw locking adhesive to at least 150°C (using a hot air gun if necessary), then unscrew it using the special wrench **ID134984**, which can be operated with a SW13 open-end wrench.

!! Please note that the ring ID179873 has a left-hand thread !!

The replacement of the tightening screw ID179731 has been completed.

To reattach the ring, please follow the relevant instructions for use from Loctite®.

179728



134984

